

PARKLAND PARTY

&

EQUIPMENT RENTALS LTD.

5929-48th Avenue, Red Deer, Alberta T4N 3V4

Ph: (403) 347-7733 Fax: (403) 347-7066

www.parklandrentals.com - sales@parklandrentals.com

Helium

OPERATION

Keep cylinder caps in place whenever cylinders are moved or stored. Always store cylinders in a well-ventilated area and in an upright secured position so they can not be tipped or pushed over. Transport cylinders only in a well-ventilated vehicle. Always use a regulator designed for balloon filling operations. Contact your supplier if questions arise or if more information is needed. Check all connections for leaks before filling balloons. **DO NOT USE LEAKY EQUIPMENT.** Close the cylinder valve after each use and when cylinder is empty. Do not breathe helium from a cylinder or balloon. Do not leave cylinder unattended.

Never place cylinders where they could come in contact with an electrical circuit. Do not store cylinders in direct sunlight or near sources of radiant heat. Never use cylinders as rollers. Never allow cylinders to drop or strike together violently. Do not allow anyone to breathe helium from cylinders or from filled balloons. Do not allow children or any unauthorized people to handle cylinders or use balloon filling equipment.

Helium filled balloons last approximately 4 hours.

Hi-float treatment will make them last approximately 3 DAYS, which may be purchased at our location.

Helium acts as a simple asphyxiate displacing oxygen. If the body is deprived of oxygen, even for a very short period of time, DEATH or serious injury may occur. Exposure to atmospheres containing reduced oxygen (increased helium) will bring about unconsciousness without warning – so quickly, that you will not be able to help yourself. DO NOT UNDER ANYCIRCUMSTANCES ATTEMPT TO INHALE HELIUM. THE RESULTING LACK OF OXYGEN MAY LEAD TO DEATH. THIS MAY HAPPEN TO YOU IF YOU INHALE HELIUM.

NOTE: This product is for balloon service only. Do not use for welding application or any other use.